

TRIM FREE

Laser transfer paper for white/light textiles and tetile surfaces

STEP BY STEP

Step 1

Print the design on the plain side of TrimFree

Step 2

Position the transfer on the garment and press for 30 seconds at 165°C

Step 3

Remove the transfer paper warm (wait 7-10 seconds) **(Do not remove the textile from the heat press before the transfer paper has been removed)**

Step 4

Cover the transfer with a silicone sheet and re-press for a further 30 seconds at 165°C

WITH FOIL

Step 1

Once you have completed Steps 1-3 of the above section, place the foil on top of the transfer colour side face up. **When using foil, TrimFree can be applied onto any colour textile, (it is recommended to print your image in black)**

Step 3

Press for 30 seconds at 165°C and peel cold.

Step 4

Cover the transfer with a silicone sheet and re-press for a further 30 seconds at 165°C

PRINT SETTINGS

LASER PRINTER

Paper Mode: Heavy to Label
Image Mode: Mirror Image
Feeding: Bypass (manual feeding)

PLEASE NOTE: TRIMFREE CAN ONLY BE USED IN NON OIL BASED PRINTERS

SUITABLE FOR - WHITE AND PASTEL TEXTILES

- ▶ Cotton
- ▶ Polyester
- ▶ Polyester/Cotton

TRANSFER SETTINGS

TIME	30 seconds
RE-PRESS	30 seconds
TEMPERATURE	165°C
PRESSURE	Heavy
PEEL	Warm (wait 7-10 seconds)

CARE INFORMATION

- ▶ Up to 40°C
- ▶ **Do not** dry clean
- ▶ **Do not** tumble dry
- ▶ **Do not** ironed

PLEASE NOTE: Due to the nature of the material, slight colour change may occur following washing. TrimFree is not suitable for block imaging.

PLEASE NOTE: SAMPLES ARE AVAILABLE UPON REQUEST FOR LASER PRINTER COMPATIBILITY TESTING. DTS CANNOT BE HELD RESPONSIBLE FOR PRINTER BREAKAGES.

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of TrimFree shall be liable for any injury direct or consequential, arising out of the use of, or inability to use this range.