

# FOREVER SUBLI-DELUXE

Sublimation transfer paper for 100% polyester and polyester surfaces.

Weeding Tool ? See - [www.forevertransferpaper.com/weeding-tool](http://www.forevertransferpaper.com/weeding-tool)

<b>PRINT SETTINGS</b> Image Mode · Mirror/Reverse
--

PRESS SETTINGS			
MATERIAL	TEMPERATURE	TIME	PRESSURE
<b>POLYESTER</b>	200°C (392 F)	45-55 sec.	medium
<b>BAG/ TOTE</b>	200°C (392 F)	45-55 sec.	medium
<b>BANNER FABRICS</b>	200°C (392 F)	60 sec.	medium
<b>PLAQUES</b>	200°C (392 F)	75 sec.	medium
<b>MOUSE PAD</b>	200°C (392 F)	60-75 sec.	medium
<b>GLASS</b>	200°C (392 F)	8 min.	medium-maximum
<b>METAL</b>	200°C (392 F)	75 sec.	medium

## APPLICATION

1. Print your design.
2. Set your heat press to the correct settings for your substrate.
3. Position your substrate onto your heat press.
4. Position FOREVER Subli-Deluxe onto your substrate (printed side facing down).
5. Press according to the above settings.

These instructions are based on using an Adkins heat press, adjustments may be required depending on the press you are using.

This transfer paper is not suitable for application using a household iron.

This transfer paper is suitable only for Sublimation Printers.

**Are you experiencing problems with this transfer media?**

**Don't panic, it does work.**

**Call us on 01244 541 647 or E-Mail [info@forevertransferpaper.com](mailto:info@forevertransferpaper.com)**